



Thickness: approximately 0.55 mm

- 0, 50, 100, 150 and 200 are red.

- Vertical type scale plate. As the adhesive tape is provided, you can simply stick it on machines / devices to use.
- It is useful to align the adjustment shaft for a conveyance line and a slide table.
- Scale lengths of 50 / 100 / 150 / 200 mm are standardized.
- Made of stainless steel. It is highly corrosion-resistant.
- Corners are rounded. It is hard to remove.
- Has mounting holes. After sticking, it can be secured more firmly with screws.
- Adhesive tape is not provided with **FSP-50V-*-K**. Tighten the Scale Plate with screws.
- There are 3 types of scales. They can be selected by the symbol of the part number.

| Symbol | Scale |
|------------|--------------------------|
| T-K | Zero point at the bottom |
| B-K | Zero point at the top |
| C-K | Center distribution |

| | |
|-----------------|----------------|
| Material/Finish | RoHS |
| | FSP-V-K |
| Main body | SUS304 |

Precautions for Use

- **FSP-V-K** Use the scale of the Scale Plate as a general guideline.
- Thoroughly remove oil and dust on the sticking surface before sticking.
- Avoid use in high-temperature/high-humidity environments, and do not leave moisture or oil adhered to the product. The scale part may peel off.

| Part Number | L1 | L | Mass (g) |
|---------------------|-----|-----|----------|
| FSP-50V-T-K | 50 | 58 | 2.5 |
| FSP-100V-T-K | 100 | 108 | 4.7 |
| FSP-150V-T-K | 150 | 158 | 6.9 |
| FSP-200V-T-K | 200 | 208 | 9.1 |
| FSP-50V-B-K | 50 | 58 | 2.5 |
| FSP-100V-B-K | 100 | 108 | 4.7 |
| FSP-150V-B-K | 150 | 158 | 6.9 |
| FSP-200V-B-K | 200 | 208 | 9.1 |
| FSP-50V-C-K | 50 | 58 | 2.5 |
| FSP-100V-C-K | 100 | 108 | 4.7 |
| FSP-150V-C-K | 150 | 158 | 6.9 |
| FSP-200V-C-K | 200 | 208 | 9.1 |

Unit : mm



• Related Products

Point Lens **FLE**, which is useful to read the scale, is available.



Special low head bolt **SSH5** whose height of the head is low is available as a mounting bolt.



- Part number specification

FSP-200V-T-K