
FSP Scale Plates (Horizontal Type)

SUS Stainless steel

FSP-R FSP-R-BK Zero point on the left



FSP-L FSP-L-BK Zero point on the right

100 90 80 70 60 50 40 30 20 10 0

FSP-C FSP-C-BK Center distribution

50 40 30 20 10 **0** 10 20 30 40 **50**

Thickness: approximately 0.55 mm

• **FSP** (Background color: Silver) Multiples of 0 and 50 are red.

• **FSP-BK** (Background color: Black) All numbers are silver.

•	Material/Finish	
---	-----------------	--

 Material/Finish 		🦸 RoHS
	FSP	
Main Body	SUS304	

ESP Background color: Silver ESP-BK Background color: Black

Tor Dackground color. Silver 13	P-BK Background color: Black		Unit : mm
Part Number 🜗	L1	L	Mass (g)
FSP-50-R	50	58	2.6
FSP-100-R	100	108	4.8
FSP-150-R	150	158	7
FSP-200-R	200	208	9.2
FSP-50-L	50	58	2.6
FSP-100-L	100	108	4.8
FSP-150-L	150	158	7
FSP-200-L	200	208	9.2
FSP-50-C	50	58	2.6
FSP-100-C	100	108	4.8
FSP-150-C	150	158	7
FSP-200-C	200	208	9.2
FSP-50-R-BK	50	58	2.6
FSP-100-R-BK	100	108	4.8
FSP-150-R-BK	150	158	7
FSP-200-R-BK	200	208	9.2
FSP-50-L-BK	50	58	2.6
FSP-100-L-BK	100	108	4.8
FSP-150-L-BK	150	158	7
FSP-200-L-BK	200	208	9.2
FSP-50-C-BK	50	58	2.6
FSP-100-C-BK	100	108	4.8
FSP-150-C-BK	150	158	7
FSP-200-C-BK	200	208	9.2

Scale Plate / Scale sticker Length Adjusutment

Please feel free to contact us

NNBK ▶ https://www.nbk1560.com

- Horizontal scale plate. Has adhesive tape to enable use simply by sticking to existing machinery and equipment.
- Convenient for conveyor line shaft adjustment or slide table positioning.
- Standardized 50/100/150/200 mm scale length. • Made of stainless steel. It has excellent corrosion
- resistance. • Corners are rounded. Doesn't come off easily.
- There are 3 types of scales. They can be selected by the symbol of the part number.


Symbol	Scale	
R	Zero Point on the Left	
L	Zero Point on the Right	
С	Center Distribution	

• There are two color variations available. They can be selected by the end symbol of the part number

se selected sy the end symbol of the part humber.						
End Symbol	Background Color	Scale / Numbers				
No	Silver	Red/Black				
ВК	Black	Silver				

Precautions for Use

- Use the scale of the **FSP** Scale Plate as a general guideline.
- Thoroughly remove oil and dust on the sticking surface before sticking.
- Avoid use in high-temperature/high-humidity environments, and do not leave moisture or oil adhered to the product. The scale part may peel off.



MAN&MACHINE®

Related Products

Point Lens **FLE**, which is useful to read the scale, is available.

• Part number specification **FSP-200-R-BK**

41